



INSTRUCTIONS

J00725

2013-11-01



NOSTALGIC PASSENGER FOOTBOARD KIT

GENERAL

Kit Number

50190-96

Models

For model fitment information, see the P&A retail catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

Table 1. Kit Contents

Quantity	Description
2	Footboard covers

NOTE

There are no Service Parts with this kit.

INSTALLATION

Remove passenger footboard pads. If applicable, remove the "underside" chrome footboard covers (Part No. 50782-91). If chrome passenger footboard covers are being replaced, follow these removal steps:

1. With left side passenger footboard down, select an outside "corner". Slightly raise rubber pad off footboard with a screwdriver.
2. From underneath the footboard, push the pad nipple through the hole with another screwdriver.
3. Carefully slide screwdriver under cover/pad to other front "corner". Repeat step 2.
4. Pry up rear corners with screwdriver and remove footboard cover.

Installation of chrome passenger footboard covers

1. Center the two footboard pivot pins.
2. Moisten kit footboard cover rubber nipples and footboard dowel recess holes with dishwashing soap to ease installation.
3. With footboard down, place footboard cover onto footboard with the two extended rubber nipples over holes. Firmly grasp footboard cover (bike side) and footboard with both hands. Insert dowels into footboard.
4. Pull extended nipple ends through holes to properly seat them. Cut off rubber "pull end" at the tip of each nipple. If appropriate, reattach "underside" footboard cover.
5. Repeat procedures for right side footboard cover.

NOTE

Avoid the contact of chrome surfaces with abrasive

