



INSTRUCTIONS

J00103

1995-06-01



FL CHROME BRAKE PEDAL COVER - 3 SLOT AND 5 SLOT

GENERAL

Kit Number

42478-95 (3 slot), 42557-95 (5 slot)

Models

These kits fit 1980 to 1996 FLHT, FLT, FLHR, FLHS models
1986 to 1996 FLSTC, FLSTN, FLSTF models.

Kit Contents

Table 1. Kit Contents

| Description (Quantity) | Part Number |
|--|-------------|
| Kit 42478-95, 3 slot brake pedal cover | |
| 3 slot brake pedal cover | 44227-95 |
| 3 slot rubber tread | 44228-95 |
| 3 slot fastener | 44229-95 |
| Washer, flat | 6422 |
| Washer, offset | 6421 |
| Acorn Nut | 7946 |
| Kit 42557-95, 5 slot brake pedal cover | |
| 5 slot brake pedal cover | 42558-95 |
| 5 slot rubber tread | 44234-95 |
| 5 slot fastener | 44232-95 |
| Washer, flat | 6422 |
| Washer, offset | 6421 |
| Acorn Nut | 7946 |

INSTALLATION

1. Remove previously installed brake pedal cover from motorcycle.
2. Align and place brake pedal cover over rubber tread.
3. Insert bolt, with rubber logo properly aligned, into hole in combined new brake pedal cover and rubber tread.
4. Place flat washer onto bolt.
5. Place new brake pedal cover and bolt/washer assembly on brake pedal.
6. Place offset washer on bolt.
7. Adjust and hold offset washer in position covering exposed slot under brake pedal and attach acorn nut to bolt. Tighten acorn nut to 25-29 ft-lbs (33.8-39.3 Nm).