



INSTRUCTIONS



J00187

1995-06-01

CHROME OPERATOR FOOTBOARD COVERS

GENERAL

Kit Number

50176-95

Models

This kit fits 1980 and later FLT, FLHT, FLHR, FLHS models and 1986 and later FLSTC, FLSTN, and FLSTF model motorcycles.

Kit Contents

Table 1. Kit Contents

Description (Quantity)	Part Number
Footboard covers (2)	Not Sold Separately

There are no Service Parts available with this kit.

INSTALLATION

Removal Of Previously Installed Footboard Covers:

1. With left side operator footboard in up position, use a screwdriver to work rubber footboard cover collars out through the top of the footboard.

To Install Operator Chrome Footboard Covers:

1. Moisten kit footboard cover rubber collars with dishwashing soap to ease installation.
2. With footboard in up position, firmly hold new footboard cover in installation position. From underside of footboard use a pliers to pull each rubber isolator into its footboard base hole until the thick collar emerges.
3. Repeat procedures for right side footboard cover.

NOTE

Avoid the contact of chrome surfaces with abrasive materials (stones, sand, etc.) as damage will result.

