



INSTRUCTIONS

J00207

2012-02-29



CHOPPED TOUR-PAK PASSENGER BACKREST PAD

GENERAL

Kit Numbers

51635-06, 52031-96, 52032-96, 52033-96, 52435-05, 52519-03, 52621-09, 52898-98, 53024-03, 79192-10, 52300143, 52300294, 52300298, 52300299

Models

This kit fits motorcycles equipped with a Chopped Tour-Pak®.

Kit Contents

Table 1. Kit Contents

Description (Quantity)	Part Number
Backrest pad	Not sold separately
Flanged locknut, 1/4-20 (6)	7716

INSTALLATION

Install the backrest pad on the Tour-Pak as follows:

1. Align the six backrest pad studs with the existing drilled holes in the Tour-Pak.
2. Fasten the backrest pad studs with the six 1/4-20 flanged locknuts included in the kit. Tighten the locknuts to 11 N·m (8 ft-lbs).
3. Close the Tour-Pak cover and check for proper backrest alignment.

