



INSTRUCTIONS

J00333

2013-11-01



BAR AND SHIELD CHROME FENDER TIP LENS KIT

GENERAL

Kit Number

59081-96

Models

For model fitment information, see the P&A retail catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

Table 1. Kit Contents

Quantity	Description	Part Number
1	Lens, fender tip, front (amber)	59201-96
1	Lens, fender tip, rear (red)	68081-96

INSTALLATION

1. Remove stock front (amber) fender tip lens.
2. Select amber fender tip lens from kit.
3. Place large tab on lens in groove in lower fender tip lamp housing.

NOTE

Cover the screwdriver blade with tape to prevent scratching lens.

4. Place the blade of a small screwdriver in the space between the lens and notch in the upper-center of the lamp housing. Using firm but gentle pressure between the lamp housing and the lens, pry the upper lens tabs down and push the tabs under the housing. Remove the screwdriver blade from the notch.
5. Repeat steps one through four on the rear (red) fender tip lens.

