



INSTRUCTIONS

J00335

2013-11-01



FLHT CHROME WINDSHIELD MOLDING KIT

GENERAL

Kit Number

59213-96

Models

For model fitment information, see the P&A retail catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

Table 1. Kit Contents

Quantity	Description	Part Number
3	Spacer	3673
1	Windshield molding	Not sold
3	Screws, Phillips, oval head, 1/4-20 x 1/2 in.	94539-96

NOTE

Part numbers for service parts are listed above.

INSTALLATION

1. Insert three screws from kit into countersunk holes in molding.
2. Slip rubber spacers from kit onto screws with countersunk end facing the molding.
3. With a T27 Torx driver remove the three screws and washers at the bottom of the windshield. **DO NOT REMOVE OUTER FAIRING.**
4. Align the windshield molding with the three mounting holes and thread screws into threaded inserts in inner fairing.
5. Check that molding is aligned with top of outer fairing and tighten screws to 1.1–1.4 N·m (10–13 **in-lbs**).

