



INSTRUCTIONS

J00343

2006-04-11



FLSTF FENDER TRIM

GENERAL

Kit Numbers and Descriptions

Eagle with Harley-Davidson graphics:

- Front fender, Chrome: Kit number 59285-90.
- Rear fender, Chrome: Kit number 59286-90.
- Front fender, Chrome and Gold: Kit number 59318-96.
- Rear fender, Chrome and Gold: Kit number 59317-96.

Eagle wings with Bar-and-Shield logo:

- Front fender, Chrome: Kit number 59366-97.
- Rear fender, Chrome: Kit number 59368-97.
- Front fender, Chrome and Gold: Kit number 59367-97.
- Rear fender, Chrome and Gold: Kit number 59369-97.

Models

Kits 59285-90, 59318-96, 59366-97, and 59367-97 fit 1990 and later FLSTF (Fat Boy®) front fender.

Kits 59286-90, 59317-96, 59368-97, and 59369-97 fit 1990-2006 FLSTF rear fender.

Kit Contents

Table 1. Kit Contents

Description (Quantity)	Part Number
Fender tip	Not Sold Separately
Screw (3)	Not Sold Separately
Lock nut (3)	Not Sold Separately



INSTALLATION

1. Thoroughly clean the fender tip in the area where the trim will be mounted.
2. Cover the fender with masking tape to protect the painted surface during positioning of the trim.
3. Place the trim in the desired location and hold it in position. Mark the hole locations with a felt tip pen or pencil. Remove the trim.
4. Carefully center punch the hole locations in the fender.
5. Drill the mounting holes using a 1/8 in. (3 mm) diameter drill bit.
6. Remove the masking tape from the fender.
7. Mount the trim on the fender using the screws and lock nuts provided in the kit.