



INSTRUCTIONS

J02629

2007-11-07



CHROME LOWER BELT GUARD COVER

GENERAL

Kit Number

60408-09, 60491-02A

Models

For model fitment information, please see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

This Kit consists of a chrome cover for the original equipment (O.E.) lower belt guard (debris deflector) and these instructions. There are no Service Parts available.

INSTALLATION

1. Remove the left-side saddlebag from the vehicle.
2. Remove the two rearmost screws from the original equipment (O.E.) lower belt guard. Save the screws for re-installation.
3. Slide the chrome belt guard cover over the O.E. lower belt guard, making sure the lower edge of the belt guard is inserted into the edge clip of the cover.
4. Install the two screws saved in Step 2, and tighten securely.
5. Make sure that the chrome belt guard cover does not contact the drive belt, tire or wheel. If necessary, loosen the mounting screws and reposition for clearance.

