

# **INSTRUCTIONS**



J01480

**CALIPER INSERT** 

## **GENERAL**

#### Kit Number

44474-99, 44475-99, 44476-99, 44477-99

#### Models

These kits are designed to fit front and rear brake calipers on 2000 and later models (except Springer front calipers, 2004 and later XL models, and 2006 and later VRSC model motorcycles.)

**Table 1. Kit Descriptions** 

Description	Kit Number
Flames	44474-99
V-Wing	44475-99
Harley-Davidson	44476-99
Plain chrome	44477-99

There are no Service Parts available with this kit.

### **INSTALLATION**

- 1. Leave current caliper insert installed.
- Clean existing caliper insert thoroughly with a soft cloth dampened with rubbing alcohol.
- Remove adhesive backing from new caliper insert and hold it in place over the existing caliper insert. Press the new insert firmly to activate the adhesive.