



INSTRUCTIONS

J04235

2009-07-02



LEFT SIDE TOOLBOX KIT

GENERAL

Kit Numbers

64230-08, 64216-09

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Additional Parts Required

For Models with Passenger Footrests: Separate purchase of a Hex Spacer Kit (49352-00) is required for proper installation of this kit. The Hex Spacer Kit is not required if this Toolbox Kit is installed on models with Passenger Footboard Kit (50602-00). These kits are available at a Harley-Davidson dealer.

For FLSTSB: Separate purchase of a button head screw (94399-92T), chrome washer (6595HB) and Loctite® 262 Threadlocker and Sealant - Blue is required for installation of this kit. See a Harley-Davidson dealer.

NOTE

Lock mechanism accepts all Harley-Davidson barrel-style ignition keys.

Kit Contents

See Figure 1 and Table 1.

INSTALLATION

NOTE

Be careful not to scratch toolbox surface while performing this installation.

1. See Figure 1. Attach toolbox (1) to toolbox mounting bracket (3) using three pan head screws (4) and locknuts (5).
2. **For models with passenger footboards:**
 - a. See Figure 1. Remove screw that secures passenger footboard assembly to frame (E).
 - b. Remove footboard assembly. Refer to Passenger Footboard Kit (50602-00) for instructions. Note orientation of footboard for kit installation. Save parts for kit installation.
3. **For models with passenger footrests:**
 - a. See Figure 1. Remove retaining ring (F), clevis pin (G), spring washer (H) and footrest (J).

- b. Remove screw (K) that secures the footrest support (L) to the frame (E).

4. Install toolbox mounting bracket as follows:

- a. Remove and discard one of the fender support screws (A) and washers (B). Only remove one screw and washer.
 - b. From the kit, install mounting bracket (3), one chrome washer (7) and one chrome screw (8). Hand-tighten screw.
 - c. Remove and discard the remaining original screw (A) and washer (B) from the fender support.
 - d. Rotate the mounting bracket in-line with the remaining hole and install the chrome washer (7) and chrome screw (8) from the kit. Hand-tighten screw.

▲ WARNING

Footrests must fold up and toward rear of motorcycle if struck. Failure to set footrests to fold up and back could result in death or serious injury. (00366a)

5. **For models with passenger footrests: For models with passenger footboards: For FLSTSB without passenger footrests:**
 - a. See Figure 1. Install Hex Spacer Kit (49352-00) following instructions included with kit.
 - b. Install the footrest support (L) and footrest (J) to the hex spacer (M).
 - c. See Figure 1. Install the Footboard Assembly (from Kit 50602-00) to the toolbox mounting bracket (3) in same orientation prior to removal.
 - d. Install the passenger footboard assembly screw and tighten to 47.5–61 N·m (35–45 ft-lbs).
 - e. See Figure 1. Apply 2 or 3 drops of Loctite 262 to screw (9). Install screw (9) and washer (10) and tighten to 13.5–20.3 N·m (10–15 ft-lbs).
6. Tighten both fender support screws (8) to 40.6–47 N·m (30–35 ft-lbs). Loosen one screw and retighten to 52–57 N·m (38–42 ft-lbs). Repeat for the other screw.

NOTE

Maximum toolbox weight capacity is 5 lb (2.25 kg).



is04505a



Item	Description (Quantity)	Part Number	Item	Description (Quantity)	Part Number
1	Toolbox (includes item 2)	Not Sold Separately	C	Fender support cover	
2	Lock, toolbox	45797-99	D	Fender support	
3	Bracket, toolbox mounting	Not Sold Separately	E	Frame	
4	Screw, pan head (3)	2774	F	Ring, retaining	
5	Locknut (3)	7686	G	Clevis pin	
6	Key (not shown)	64204-96	H	Spring washer	
7	Chrome washer (2)	6595HB	J	Footrest	
8	Screw, button head, TORX® (2)	3086	K	Screw	
9	Screw (purchased separately)	94399-92T	L	Support, footrest	
10	Chrome washer (purchased separately)	6595HB	M	Spacer, hex (included in Kit 49352-00 - purchased separately)	
Item mentioned in text, but not included in kit:			N	Washer (included in Kit 49352-00 - purchased separately)	
A	Screw, fender support (2)		P	Screw (included in Kit 49352-00 - purchased separately)	
B	Washer (2)				