



INSTRUCTIONS

J05802

2013-04-05



FRONT FENDER TRIM KIT

GENERAL

Kit Number

14100618

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

This kit contains one fender trim piece.

There are no service parts available with this kit.

INSTALLATION

- Ambient temperature should be between 21 °C (70 °F) and 38 °C (100 °F) for proper adhesion. Do not apply below 10 °C (50 °F).
 - Allow AT LEAST 24 hours after application before exposing the area to vigorous washing, strong water spray or extreme weather.
 - The adhesive bond will increase to maximum strength after about 72 hours at normal room temperature.
1. Using a 50:50 isopropyl alcohol/water solution, thoroughly clean the front fender mounting surface. Allow to dry completely.
 2. Mark the centerline of the fender.
 3. With the adhesive backing still in place, test fit the trim on the marked centerline. Locate the best mounting location. **Small Fender Models:** See Figure 1. Harley-Davidson recommends the trim be set back 2.5 cm (1 in) the fender tip. **Large Fender Models:** See Figure 2. Harley-Davidson recommends the trim be set back 14 cm (5.5 in) the fender tip.
 4. Remove the adhesive backing from the trim. Install the trim to the fender.
 5. Press the trim firmly to make sure that there is good adhesion.



Figure 1. Front Fender Trim Placement - Small Fenders




Figure 2. Front Fender Trim Placement - Large Fender