INSTRUCTIONS

CONSOLE COVER KIT

GENERAL INFORMATION

Table 1. General Information

| Kits	Suggested Tools	Skill Level[1]
52300409	Safety glasses, grease pencil, isopropyl alcohol	1 Dark wrench
(1) Only simple tools and techniques required		

KIT CONTENTS

Figure 1. Kit Contents: Console Cover Kit

Table 2. Kit Contents: Console Cover Kit

✓	Item	Qty	Description	Part No.	Notes
	\multicolumn		Verify that all contents are present in the kit before installing or removing items from vehicle.		
☐	1	1	Console cover	Not sold separately	
☐	2	1	Medallion	Not sold separately	

GENERAL

Models

For model fitment information, see the Parts and Accessories (P&A) Retail Catalog or the Parts and Accessories section of www.harley-davidson.com.

Verify that the most current version of the instruction sheet is used. It is available at: h-d.com/isheets

Contact Harley-Davidson Customer Support Center at 1-800-258-2464 (U.S. only) or 1-414-343-4056.

Installation Requirements

⚠ WARNING

Rider and passenger safety depend upon the correct installation of this kit. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00308b)

PREPARE

1. See Figure 1. Bond medallion (2) to console cover (1).

   a. Medallion should be evenly spaced.

2. See Figure 2. Test fit console cover (3).

3. Clean console (2) area with isopropyl alcohol. Dry with a lint free cloth.

4. Use a grease pencil to mark location.

INSTALL

- Ambient temperature during installation must be at least 68° F (20° C).
- Installation at temperatures below 68° F (20° C) will cause failure of the adhesive bond.
- Do not sand or scuff surface where inserts are to be installed.
- After installing, allow a minimum of 24 hours before exposing the area to vigorous washing, strong water spray or extreme weather.

1. See Figure 2. Remove adhesive backing from console cover (3).

2. Install console cover (3) using marks made earlier as a guide.

3. Press firmly in place with steady pressure for one minute.

1615651

1.	Airbox cover
2.	Console
3.	Console cover

Figure 2. Console Trim Installed