
# **INSTRUCTIONS**



J05751

## **OUTER FAIRING SKIRT**

#### **GENERAL**

#### Kit Number

57100227

#### Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

#### **Kit Contents**

This kit contains one outer fairing skirt. There are no service parts available for this kit.

### **Additional Parts Required**

#### **A WARNING**

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333b)

#### NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson dealer.

#### **REMOVAL**

#### **A WARNING**

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse before proceeding. (00251b)

- 1. Remove main fuse.
- 2. Remove outer fairing and windshield following the instructions in the service manual.
- Remove front turn signals following the instructions in the service manual.
- 4. See Figure 1.Remove the stock fairing skirt. Save double studs (2) for installation.




Figure 1. Inner Fairing and Skirt

#### INSTALLATION

- See Figure 1. Install new fairing skirt with double studs (2). Tighten double studs to 13.6–20.3 N·m (120–180 in-lbs).
- 2. Install front turn signals following the instructions in the service manual.
- 3. Install outer fairing and windshield following the instructions in the service manual.

#### **Kit Contents**




Figure 2. Kit Contents: Outer Fairing Skirt