



INSTRUCTIONS

J05988

2014-09-12



CLUTCH MASTER CYLINDER REBUILD KIT

GENERAL

Kit Number

37200096A

Models

For model fitment information, See the Parts Catalog.

⚠ WARNING

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333b)

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation. One is available from a Harley-Davidson Dealer.

Kit Contents

See Figure 2 and Table 1.

Installation Requirements

Proper installation of this kit requires new, clean hydraulic brake fluid. See the owner's manual for the specified brake fluid.

KIT INSTALLATION

NOTE

Kit contains different sealing washers depending on model. See Figure 1, to identify sealing washer needed for installation.

1. See the service manual and follow the instructions given to remove clutch master cylinder and reservoir.
2. Compare removed sealing washers with washers from kit.
3. Set aside **new** sealing washers needed for installation.
4. Discard remaining washers.

5. See the service manual and follow the instructions given to disassemble, assemble and install clutch master cylinder and reservoir.




Figure 1. Sealing Washers



SERVICE PARTS




Figure 2. Service Parts: Clutch Master Cylinder Rebuild Kit

Table 1. Service Parts Table

Item	Description (Quantity)	Part Number
1	Piston assembly (includes items 2 through 7	Not Sold Separately
2	• Spring	Not Sold Separately
3	• Primary cup	Not Sold Separately
4	• Retaining ring	Not Sold Separately
5	• Piston	Not Sold Separately
6	• Secondary cup	Not Sold Separately
7	• Boot	Not Sold Separately
8	Lubricant	Not Sold Separately
9	Retaining ring	11143
10	Sealing Washer, copper (2)	41751-06A
11	Sealing Washer, steel/rubber (2)	41731-01
12	Sealing Washer, steel/rubber (2)	41756-08
13	Sealing Washer, steel/rubber (2)	41733-88