J06790

# **INSTRUCTIONS**

2019-08-22

2019-

# **BLACK MILWAUKEE-EIGHT TRANSMISSION KIT**

**Table 1. General Information** 

Kits	Suggested Tools	Skill Level <sup>(1)</sup>	Time				
12600253	12600253 Safety Glasses, Torque Wrench		2 hours				
(1) Tightening to torque value or other moderate tools and techniques required							

### **KIT CONTENTS**




Figure 1. Kit Contents: M8 Transmission Components

**Table 2. Kit Contents: M8 Transmission Components** 

	Item	Qty	Description	Part No.	Replace	Notes
	1	8	Screw, Softail	10200947	4741A	Follow torque specification and
	┦ ' │	6	Screw, Touring			torque sequence per service manual
	2	8	Screw	10200949	3249	Follow torque specification and torque sequence per service manual Installation requires removal of exhaust
3		3	Screw, Softail	10200951	4718A	Follow torque specification and
	3		Screw, Touring			torque sequence per service manual Installation requires removal of ex- haust
	4	1	Screw	10200972	4705	Softail models only Follow torque specification and torque sequence per service manual
	5	1	Plug/Dipstick, oil filter	62700279	37065-06A	

#### NOTE

Verify all contents are present in the kit before installing or removing items from vehicle.

#### **GENERAL**

#### **Models**

For model fitment information, please see the P&A Retail Catalog or the Parts and Accessories section of www.harley -davidson.com (English only).

Ensure you are using the most current version of the instruction sheet which is available at: www.harley-davidson.com/isheets

Contact Harley-Davidson Customer Support Center at 1-800-258-2464 (U.S. only) or 1-414-343-4056.

## Installation Requirements

#### **A WARNING**

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333b)

#### **INSTALLLATION**

Remove and Replace

#### NOTE

- See the service manual of the year and model vehicle that the service is being performed on for the following steps.
- Follow torque specification and installation sequence per service manual for screws (1 thru 4).
- Remove and replace each screw one at a time to maintain initial clamp load.
- Texture black touch-up pen (98605BF) or bottle (98600BF) can be used for coverage of imperfection on engine covers.
- 1. Fully remove one Original Equipment (OE) screw.

- 2. Install new black screw.
- 3. Tighten screw. See service manual.
- Repeat steps for remaining screws. Replace screws individually following torque sequence per service manual.
- Install new black plug/dipstick (5).

2/2 J06790