

## TRANSPORT MODE

The transport mode is used for moving the vehicle or transporting on a trailer with the security system armed and without tripping the alarm. When the vehicle is in the transport mode, the security system **does not respond to motion detection**.

- To exit the transport mode, use the key fob to disarm the vehicle.
- To enter the transport mode, refer to Table 9.

## Disabling Security System

Disarm the security system using the key fob or personal code. At this point, the security fuse may be removed or battery disconnected.

### NOTE

*Transport mode is especially useful when working on HDI vehicles. If it is not used, the alarm will activate under many typical service activities.*

**Table 9. Transport Mode**

<b>STEP NO.</b>	<b>ACTION</b>	<b>WAIT FOR CONFIRMATION</b>	<b>NOTES</b>
1	Turn <b>IGN</b> key <b>ON</b>		
2	Press and hold <b>key fob</b> button until confirmation is received	3 flashes turn signals & indicators	
3	Turn <b>IGN</b> key <b>OFF</b>		
4	Press and hold <b>key fob</b> button until confirmation is received	3 flashes turn signals & indicators	The vehicle can be moved without tripping the alarm