VEHICLE ALIGNMENT

Isolation Mounted Engine Models

The stabilizer links and engine mounts should be checked for wear according to service manual procedures after the first 1,000 miles (1,600 km) and every 5,000 miles (8,000 km) thereafter and whenever the rear wheel is removed and installed or when the rear drive belt is adjusted.

Vehicle alignment is important. Vehicle stability is adversely affected if wheels are out of alignment. Major alignment of the front and rear wheel is partially controlled by one or two stabilizer links. One at the top of the engine and one at the front of the engine.

⚠WARNING

Do not change the adjustment of the stabilizer link(s). Changing the adjustment as little as 1/3 turn could adversely affect motorcycle stability which could result in death or serious injury.

See your Harley-Davidson Dealer for this service.

⚠WARNING

Major vehicle alignment should be performed only by your Harley-Davidson Dealer using service manual procedures. Improper vehicle alignment will adversely affect motorcycle handling and stability, which could result in death or serious injury.