

INSTRUCTIONS



REAR AGITATOR WHEELS

GENERAL

A WARNING

J04979

Install only wheels and installation kits approved for your model motorcycle. Contact a Harley-Davidson dealer to verify fitment. Mismatching wheels and installation kits or installing wheels not approved for your model can cause loss of control, which could result in death or serious injury. (00610c)

Kit Numbers

40225-10, 47951-10, 47951-10A, 40900112, 40900459

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

See Figure 1 and the Service Parts Tables.

Additional Parts Required

Separate purchase of tire (44006-09) is required for proper installation of this kit.

This kit includes custom wheel only.

Proper installation of this kit requires the separate purchase of the following parts which are available at a Harley-Davidson dealer:

- Wheel Installation Kit (See Table 3 and Table 4 to determine required installation kit.)
- Brake Disc Screws (See Table 1 to determine proper hardware.)
- Rear Sprocket Screws (See Table 1 to determine proper hardware.) See the P&A Retail Catalog for chrome sprocket hardware.
- Wheel Bearing Remover and Installer (94134-09)

A WARNING

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333b)

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson dealer.

Recommended Additional Parts

The following Harley-Davidson Genuine Motor Accessories are recommended for proper maintenance and cleaning:

2021-01-20

- Harley[®] Bright[™] Chrome Cleaner (94683-99) (Not for use on kit 40900112)
- Harley[®] Glaze[™] Polish and Sealant (99701-84)
- Harley[®] Wheel and Spoke Brush (43078-99)
- Harley-Davidson[®] Wheel and Tire Cleaner (94658-98)
- Harley[®] Preserve Bare Aluminum Protectant (99845-07)

Table 1. Rear Disc and Sprocket Hardware Fitment

Hardware	Fitment						
Rear Disc Screws (select stock or chrome hardware)							
5 Stock disc screws (43567-92)							
Chrome screw kit (46647-05) in-	All models						
cludes 5 screws							
Rear Sprocket Screws (select s							
5 Sprocket screw, stock (3109)	2007 and later Dyna and						
	Softail, 2007 Touring						
Chrome screw kit (94773-07) in-	2007 and later Dyna and						
cludes 5 screws and washers	Softail						
5 Sprocket screw, stock (3737A)	2000-2005 Dyna, 2000-						
	2006 Softail, 2004-2006						
	Touring						
Chrome screw kit (94773-00A)	2000-2005 Dyna, 2000-						
includes 5 screws and washers	2006 Softail						
5 Sprocket screw, stock (3814)	2008 Touring						
5 Sprocket screw, stock (3873)	2006 Dyna						
5 Sprocket screw, stock (3899)	2000-2003 Touring, 2001						
	and later Sportster (except						
	Japanese models)						
5 Sprocket screw, stock (40439-	2002-2006 VRSC and 2007						
01)	VRSCR models						
5 Sprocket screw, stock (4552)	2007 and later VRSC mod-						
	els (except VRSCR and						
	VRSCSE models)						
Rear Sprocket Washers							
5 Sprocket washer, stock	2006 and earlier Dyna, Sof-						
(6516HW)	tail and Touring and 2000						
	and later Sportster models						
	(except Japanese models)						
5 Sprocket washer, stock (7039)	2002 and later VRSC						

INSTALLATION

NOTE

Use plastic protectors on tire mounting tools and rim clamps when mounting a tire to a painted wheel.

When mounting tires, liberally use tire lube on the wheel and tire

For tire removal, use plastic inserts between the rim and tire after breaking the bead to create a large enough gap for the rim clamps to get into.

Before removing or installing the wheel, the rear brake caliper must be removed. The cotter pin or spring clip for the axle nut must be replaced. They are available for separate purchase from a Harley-Davidson dealer. See dealer for the correct part number.

 Remove existing rear wheel assembly. Save axle, axle nut, brake disc and wheel spacers for kit installation. See the service manual.

NOTE

Install short valve stem (43157-83A) included in the installation kit. Discard all other valve stems.

See Figure 1. Install valve stem assembly (H) on wheel. See the service manual.

NOTICE

Do not re-use brake disc/rotor screws. Re-using these screws can result in torque loss and damage to brake components. (00319c)

NOTICE

Do not re-use sprocket mounting screws. Re-using sprocket mounting screws can result in torque loss and damage to the sprocket and/or belt assembly. (00480b)

- Assemble wheel installation kit components, stock brake disc and sprocket to wheel, using the appropriate service parts table. See the service manual.
- Install primary bearing with a Wheel Bearing Remover and Installer. See the service manual. The machined groove(s) indicates the primary bearing side.

NOTE

Install the required (separately purchased) tire.

If the wheel has a yellow dot sticker on the rim, orient the tire so the white dot is opposite of the sticker. If the wheel has a green dot sticker on the rim, orient the tire so the white dot is aligned with the sticker. If no rim dot sticker is present, see the service manual.

- Mount new tire (purchased separately) to the wheel. See the service manual.
- Install rear wheel (1), stock axle, sprocket and stock spacers to motorcycle. See the service manual.

MAINTENANCE AND CLEANING

Chrome parts must be maintained regularly so they keep their original shine and luster.

- Clean heavily-soiled wheel surfaces using Harley-Davidson Wheel and Tire Cleaner, applied with Harley Wheel and Spoke Brush.
- 2. Thoroughly clean chrome with a good quality chrome cleaner, such as Harley Bright Chrome Cleaner.
- 3. After cleaning and polishing, seal the finish with a good quality sealer, such as Harley Glaze Polish and Sealant.

SERVICE PARTS




Figure 1. Service Parts: Rear Agitator Wheel (18-inch shown)

2/3 J04979

Table 2. Service Parts and Wheel Kit Contents

Kit	Item	Description (Quantity)	Part Number				
40225-10, 47951-10,	1	Wheel	Not Sold Separately				
47951-10A, 40900112,							
40900459							
Visual indicator mentioned in text:							
4 Machined groove (all wheels)							

Table 3. REAR 25mm Bearing Wheel Installation Kit (41456-08C)

REAR 25 MM Bearing Wheel Installation Kit (41456-08C)		Item (Quantity Used and Description)									
Fitment	Wheel Size	Α	С	D	E	F	Н	I	J		
2009 and later FLT without ABS	16 x 5.0 in	2	1	0	0	0	*	*	*		
2009 and later FLT without ABS	18 x 5.0 in	2	1	0	0	0	*	*	0		
2008 VRSCD without ABS	18 x 5.5 in	2	0	0	1	**	*	*	0		
2013 and later FXSB, 2008 and later FXCW/C without	18 x 8.0 in	2	0	1	0	0	*	*	0		
ABS				'		U			0		
2008 and later VRSCAW, VRSCDX and VRSCF without	18 x 8.0 in	2	0	0	1	**	*	*	0		
ABS					'						
Installation kits are designed to work with many different wheel styles and		Α	Bearir	ng, reg	9276A						
fitments. Contact a Harley-Davidson dealer to verify that the wheel and in-		С	Axle sleeve					41349-07			
stallation kits are both designed and approved for the motorcycle they are		D	Axle s	sleeve	41358-08						
being installed on.		Е	Axle s	sleeve	43704-08						
NOTES:			Bearir	ng shir	41447-08						
* See <i>NOTE</i> above valve installation step in INSTALLATION to determine		Н	Valve	stem,	43157-83A						
which valve stem to use for your particular kit. Discard other valve stem(s).		ı	Valve	stem,	43206-01						
** See INSTALLATION to determine if shim is required.		J	Valve stem, pull thru 40999-87								
*** Bearing shim installed under primary bearing.					-						

Table 4. REAR 25 MM Bearing ABS Wheel Installation Kit (41453-08C)

REAR 25 MM Bearing ABS Wheel Installation Kit (41453-08C)			Item (Quantity Used and Description)									
Fitment	Wheel Size	Α	В	С	D	Е	F	G	Н		J	
2008 FLT with ABS	16 x 3.0 in	1	1	0	1	0	0	1	*	*	0	
2014 and later XL with ABS (except 2014 and later 883L)	16 x 3.0 in	1	1	0	1	0	0	1	*	*	0	
2009 and later FLT with ABS	16 x 5.0 in	1	1	1	0	0	0	0	*	*	*	
2009 and later FLT with ABS	18 x 5.0 in	1	1	1	0	0	0	0	*	*	0	
2008 VRSCDa with ABS	18 x 5.5 in	1	1	0	0	1	**	0	*	*	0	
2008 and later VRSCAWa, VRSCDXa, VRSCXa and VRSCFa with ABS	18 x 8.0 in	1	1	0	0	1	**	0	*	*	0	
Installation kits are designed to work with many different wheel styles		Α	Bearing, regular							9276A		
and fitments. Contact a Harley-Davidson dealer to verify that the wheel		В	Bearing, ABS**							9252		
and installation kits are both designed and approved for the motorcycle they are being installed on.		С	Axle sleeve							41349-07		
		D	Axle sleeve							41900-08		
NOTES:			Axle sleeve							43704-08		
* See NOTE above valve installation step in INSTALLATION to determine which valve stem to use for your particular kit. Discard other		F	Bearing shim***							41447-08		
		G	Bearing shim***							43904-08		
valve stem(s).			Valve stem, short							43157-		
** Primary bearing. Bearing must be installed with red side facing the										83A		
wheel.		ı	Valve	stem	, long					4320	6-01	
*** Bearing shim installed under primary bearing.		J	Valve stem, pull thru							40999-87		

J04979 3 / 3